AURA CORE

# FLEX

NETWORK AUDIO
MATRIX DSP




SHOWN: FLEX 1208 / FRONT + REAR

UP TO
**34×34**
DANTE AUDIO CHANNELS

A flexible bridge between local audio and a connected installation, with AURA NEXUS I/O on the network.

TWO ANALOG I/O CONFIGURATIONS

## FLEX 88

8 analog inputs / 8 analog outputs

## FLEX 1208

12 analog inputs / 8 analog outputs





# Connect locally. Expand over Dante.

Combine analog audio and central DSP with network I/O and amplification across the AURA ecosystem.

01 **Dante audio**
Up to 34×34 network audio channels.


02 **Matrix + DSP**
Process, mix and route local and network audio.

03 **Distributed I/O**
Place AURA NEXUS where analog audio enters or leaves the network.

04 **Unified control**
AURA NETCONTROL interfaces and ProMG software.

ONE CONNECTED INSTALLATION

Dante audio — Analog audio - - - Control




CORE PROCESSES. NEXUS CONNECTS. AXION AMPLIFIES.

One platform linking processing, distributed I/O, control and network amplification.